

# SITRANS F M MAGFLO®

*Electromagnetic flowmeters*

*Transmitter types MAG 5000, MAG 6000*



Technical Documentation (handbooks, instructions, manuals etc.) on the complete product range SITRANS F can be found on the internet/intranet on the following links:


English: <http://www4.ad.siemens.de/WW/view/en/10806951/133300>

**Order no.: FDK-521H0739**

SFIDK.PS.027.Z8.02



## 1.1 Transmitter type MAG 5000 &amp; MAG 6000

		<b>MAG 5000 accuracy 0.5%</b> <b>MAG 6000 accuracy 0.25%</b>	
<b>Current output</b>			
Current	0-20 mA, 4-20 mA or 4-20 mA + alarm		
Load	< 800 ohm		
Time constant	0.1-30 s adjustable		
<b>Digital output</b>			
Frequency	0-10 kHz, 50% duty cycle		
Time constant	0.1-30 s adjustable		
Active	24 V DC, 30 mA, $1\text{ K}\Omega \leq R_{\text{load}} \leq 10\text{ K}\Omega$ , short-circuit-protected		
Passive	3-30 V DC, max. 110 mA, $200\ \Omega \leq R_{\text{load}} \leq 10\text{ K}\Omega$		
<b>Relay</b>			
Time constant	Changeover relay, time constant same as current time constant		
Load	42 V AC/2 A, 24 V DC/1A		
<b>Digital input</b>		11-30 V DC, $R_i = 4.4\text{ K}\Omega$	
Activation time	50 ms		
Current	$I_{11\text{ V DC}} = 2.5\text{ mA}$ , $I_{30\text{ V DC}} = 7\text{ mA}$		
<b>Functions</b>		Flow rate, 2 totalizers, low flow cut-off, empty pipe cut-off, flow direction, error system, operating time, uni/bidirectional flow, limit switches, pulse output, control for cleaning unit and batch <sup>2)</sup>	
<b>Galvanic isolation</b>		All inputs and outputs are galvanically isolated	
<b>Cut-off</b>			
Low flow	0-9.9% of maximum flow		
Empty pipe	Detection of empty pipe <sup>1)</sup>		
<b>Totalizer</b>		Two eight-digit counters for forward, net or reverse flow	
<b>Display</b>		Background illumination with alphanumerical text, 3 x 20 characters to indicate flow rate, totalized values, settings and faults	
	Reverse flow indicated by negative sign		
Time constant	Time constant as current output time constant		
<b>Zero point adjustment</b>		Automatic	
<b>Electrode input impedance</b>		$> 1 \times 10^{14}\ \Omega$	
<b>Excitation frequency</b>		Sensor size depending pulsating DC current (125 mA)	
<b>Ambient temperature</b>		Display version during operation: -20 to +50°C	
		Blind version during operation: -20 to +60°C	
		During storage: -40 to +70°C (RH max. 95%)	
<b>Custody transfer approval</b>		PTB (cold water) 6.221 99.19	DANAK OIML R75 <sup>2)</sup> (hot water)
		DANAK OIML R117 <sup>2)</sup> (cold water/milk, beer etc.)	
<b>Communication</b>			
Standard	Prepared for client mounted add-on modules <sup>2)</sup>		
Optional	HART, Profibus PA & DP, Modbus RTU, CANopen, DeviceNet as add-on module <sup>2)</sup> , HART (MAG 5000)		
<b>Compact</b>			
Enclosure material	Fibre glass-reinforced polyamide		
Enclosure rating	IP 67 to EN 60529 and DIN 40050 (1 m w.g. for 30 minutes)		
Mechanical load	18-1000 Hz random, 3.17 G rms in all directions to EN 60068-2-36		
<b>19" insert</b>			
Enclosure material	Standard 19" insert of aluminium/steel (DIN 41494)		
	Width: 21 TE		
	Height: 3 HE		
Enclosure rating	IP 20 to EN 60529 and DIN 40050		
Mechanical load	Version: 1 G, 1-800 Hz sinusoidal in all directions to EN 60068-2-36		
<b>EMC performance</b>		Emission: EN 50081-1 (Light industry)	
		Immunity: EN 50082-2 (Industry)	
<b>Supply voltage</b>		115-230 V AC +10% to -15%, 50-60 Hz	
		11-30 V DC or 11-24 V AC	
		Fuse: 250 V ~ 500 mA T	
<b>Power consumption</b>		230 V AC: 17 VA	
		24 V DC: 9 W, $I_N = 380\text{ mA}$ , $I_{ST} = 8\text{ A}$ (30 ms)	
		12 V DC: 11 W, $I_N = 920\text{ mA}$ , $I_{ST} = 4\text{ A}$ (250 ms)	

1) Special cable required in separate mounted installation

2) MAG 6000 only

1.2 Output characteristics MAG 5000 & MAG 6000

Output characteristics	Bidirectional mode		Unidirectional mode	
	0-20 mA		0-20 mA	
0-20 mA				
4-20 mA				
Frequency				
Pulse output				
Relay	Power down		Active	
Error relay	No error		Error	
Limit switch or direction switch	1 set point		2 set points	
	Low flow (Reverse flow)		Intermediate flow	
	High flow (Forward flow)		High flow/ Low flow	
Batch on digital output (MAG 6000 only)				
Batch on relay (MAG 6000 only)	Hold		Batch	

1.3.1 Sensor cables and conductivity of medium


Conductivity of medium	<b>Compact installation:</b> Liquids with an electrical conductivity $\geq 5 \mu\text{S/cm}$ . For a conductivity between 5 and $10 \mu\text{S/cm}$ , the repeatability may degrade to $\pm 0.5\%$ of actual flow.	
	<p><b>Remote installation:</b></p> <p>Standard cable</p>	<p>Special cable</p>

**Note** For detection of empty sensor the min. conductivity must always be  $\geq 20 \mu\text{S/cm}$  and the max. length of electrode cable when remote mounted is 50 metres. Special cable must be used. For remote mounting in Ex applications special cable cannot be used, empty sensor cannot be detected and the electrical conductivity must be  $\geq 30 \mu\text{S/cm}$ . For remote mounted CT installations the max. cable length is 200 metres.

1.3.2 Minimum accept data for cable

		Coil cable	Electrode cable
Basic data	No. of conductors	2	3
	Min. sq. area	0.5 mm <sup>2</sup>	0.2 mm <sup>2</sup>
	Screen	Yes	Yes
	Max. capacitance	N.A.	350 pF/m
Max. cable loop resistance	Media temperature: $< 100^\circ\text{C}$	40 $\Omega$	N.A.
	$< 200^\circ\text{C}$	6 $\Omega$	N.A.

2.1 Transmitter  
MAG 5000 & MAG 6000  
connection diagram



**Note**  
Special cable with individual wire shields (shown as dotted lines) are only required when using empty pipe function or long cables. (See "Technical data")



**Potential Hazards / Grounding**

The mains protective earth wire must be connected to the PE terminal in accordance with the diagram (class 1 power supply).

**Mechanical counters**

When mounting a mechanical counter to terminals 57 and 58 (active output), a 1000 µF capacitor must be connected to the terminals 56 and 58. Capacitor + is connected to terminal 56 and capacitor – to terminal 58.

**Output cables**

If long cables in noise environment, we recommend to use screened cable.


**Electrodes cables**

Dotted connections only to be when using special electrode cable.



Mains supply 115 to 230 V AC from building installation Class II. A switch or circuit-breaker (max. 15 A) shall be included in the building installation. It must be in close proximity to the equipment and within easy reach of the operator, and it shall be marked as the disconnecting device for the equipment.

**3.1 Compact installation  
MAG 5000 & MAG 6000  
- Compact polyamide**



**Note**  
System will **not** register flow if black plugs are not connected to connection board

**Caution**  
Exposing the transmitter to direct sunlight may increase the operating temperature above its specified limit, and decrease display visibility

**Step 1**  
Remove and discard the terminal box lid of the sensor.

Fit the PG 13.5 cable glands for the supply and output cables.

**Step 2**  
Remove the two black plug assemblies for coil and electrode cables in the terminal box and connect them to their corresponding terminal numbers on the connection board.

**Step 3**  
Connect an earth wire between PE on connection board and bottom of terminal box. Connect the 2 pin connector and 3 pin connector as shown.

**Note**  
In earlier version the 3 pin connector was a 5 pin connector.


**Step 4**  
Mount the connection plate in the terminal box. The SENSORPROM® unit connections will be established automatically when the connection plate is mounted in the terminal box.

**Note**  
Check that your connection board lines up with the SENSORPROM® unit, if not, move the SENSORPROM® unit to the other side of the terminal box.

**Step 5**  
Fit the supply and output cables respectively and tighten the cable glands to obtain optimum sealing. Please refer to the wiring diagram "Electrical connections".


Mount the transmitter on the terminal box.

3.2.1 Remote installation -  
At the sensor




Remove the SENSORPROM® unit from the sensor and mount it on the connection plate in the transmitter.

Fit and connect the electrode and coil cables as shown in "Electrical connections". The unscreened cable ends must be kept as short as possible. The electrode cable and the coil cable must be kept separate to prevent interference. Tighten the cable glands well to obtain optimum sealing.




**!** Mount the terminal box lid before power up.

3.2.2 Remote installation -  
Wall mounting transmitter



Mount wall bracket on a wall or on a pipe using ordinary hose clips or duct straps.




Take the SENSORPROM® memory unit from the sensor. Mount the SENSORPROM® unit in the wall mounting unit as shown. The text on the SENSORPROM® unit **must** face towards the wall bracket.

Mount an earth wire between PE on connection board and bottom of terminal box.

**3.2.2 Remote installation - Wall mounting transmitter (continued)**

**Caution**  
Exposing the transmitter to direct sunlight may increase the operating temperature above its specified limit, and decrease display visibility




Mount the connection plate in the terminal box. Fix the connection plate with the two diagonal opposite screws.

Fit the coil, electrode, supply and output cables respectively and tighten the cable glands to obtain optimum sealing. Please see the wiring diagram in "Electrical connections".

Mount the transmitter on the terminal box.

**⚠ Attention**  
When remote mounted, power supply PE wire must be connected to PE terminal. Coil cable shield must be connected to SHIELD terminal. Use the supplied insulating tube to insulate the core shield.

**3.2.3 Remote installation - Transmitter in 19" insert**



1. Fit the SENSORPROM® memory unit on the connection board supplied with the transmitter. The SENSORPROM® unit is supplied with the sensor in the terminal box.
2. Mount the guide rails into the rack system as shown. Distance between guide rails is 20 TE. Guide rails are supplied with the rack system and not with the transmitter.
3. Mount the connection board as shown.
4. Connect the cables as shown under "Electrical connection".
5. Insert the transmitter into the rack system.

4.1 MAG 5000 & MAG 6000

TOP UP KEY



This key (hold 2 sec.) is used to switch between operator menu and setup menu. In the transmitter setup menu, a short press will cause a return from a submenu

PAGE FORWARD KEY



This key is used to step forward through the menus.

PAGE BACKWARD KEY



This key is used to step backward through the menus.

CHANGE KEY



This key changes the settings or numerical values.

SELECT KEY




This key selects the figures to be changed.

LOCK/UNLOCK KEY



Process activation



- 1) Mag 6000 I only
- 2) Add on module
- 3) Factory set password: 1000
- 4) Not at Batch
- 5) At Batch only




4.1 MAG 5000 & MAG 6000 (continued)




The fields are reserved for the following symbols:

- Alarm
- Ready for change
- Value locked
- Access to submenu
- Process activation
- Communication mode
- Service mode
- Batch can be paused
- Operator menu
- Product identity
- Language mode
- Basic settings
- Output
- External input
- Sensor characteristics
- Reset mode
- Operator menu active
- Operator menu not active



830794-13.13.02

## 4.2 Keypad and display layout



### Keypad

The keypad is used to set the flowmeter. The function of the keys is as follows:

TOP UP KEY		This key (hold 2 sec.) is used to switch between operator menu and setup menu. In the transmitter setup menu, a short press will cause a return to the previous menu.
FORWARD KEY		This key is used to step forward through the menus. It is the only key normally used by the operator.
BACKWARD KEY		This key is used to step backward through the menus.
CHANGE KEY		This key changes the settings or numerical values.
SELECT KEY		This key selects the figures to be changed.
LOCK/UNLOCK KEY		This key allows the operator to change settings and gives access to submenus.

### Display

The display is alphanumerical and indicates flow values, flowmeter settings and error messages.

The upper line is for primary flow readings and will always show either flow rate, totalizer 1 or totalizer 2. The line is divided into 3 fields.

S: Sign field  
P: Primary field for numerical value  
U: Unit field

The centre line is the title line (T) with individual information according to the selected operator or setup menu.

The lowest line is the subtitle line (ST) which either will add information to the title line or keep individual information independent of the title line.

**F: The alarm field.** **Two flashing triangles will appear by a fault condition.**


M: The mode field. The symbols indicate the following.

	Communication mode		Basic settings		Operator active
	Service mode		Output		Operator inactive
	Operator menu		External input		
	Product identity		Sensor characteristics		
	Language mode		Reset mode		

L: The lock field. Indicates the function of the lock key.

	Ready for change		Access to submenu
	Value locked		RESET MODE: Zero setting of totalizers and initialization of setting

4.3.1 Basic settings



**Main frequency**

To select the main power supply frequency corresponding to the country in which the flowmeter is installed. (US = 60 Hz)

**Flow direction**

Select the correct flow direction in the pipe.

**Q<sub>max.</sub>**

Sets the measuring range, the analog outputs and the frequency output. Value, decimal point, unit and time can be set individually (setting is dimension dependent).

**Q<sub>max.2</sub>**

Sets the measuring range, the analog outputs and the frequency output. Value, decimal point, unit and time can be set individually (setting is dimension dependent). Only visible when it has been chosen as external digital input.

**Totalizers**

To set unit and decimal point.

**Low flow cut off**

To set a % of selected Q<sub>max.</sub>. To filter noise in the installation. Influences display and all outputs.



**Error level**



To select which error level, the flowmeter will detect an error.

**Empty pipe cut off**

Set on - the alarm will indicate when sensor is running empty. All readings, display and outputs will indicate zero.

Comma for flow rate, totalizer 1 and totalizer 2 can be individually positioned.

- open the respective window.
- ensure that the cursor is positioned below the comma. Use the SELECT KEY .
- move the comma to the requested position. Use the CHANGE KEY .


Units are changed by means of the CHANGE KEY  with the cursor placed below the unit selected. Select units (cursor moved) by means of the SELECT KEY .

**Totalizer 2 is not visible when batch is selected as digital output.**

**Q<sub>max. 2</sub> - is only visible when it has been chosen as external input.**


4.3.2 Outputs

**Current output**  
**Proportional to flowrate**  
**(Terminal 31 and 32)**




The current output must be set off when not used.


**Digital output**  
**Pulse/volume**  
**(Terminal 56, 57, 58)**



**Digital output**  
**Frequency**  
**Proportional to flowrate**  
**(Terminal 56, 57, 58)**




4.3.3 External input




Batch control is available on MAG 6000 only.

4.3.4 Sensor characteristics


If "SENSORPROM not installed" is shown, refer to chapter 6 in the handbook (depending on type of mounting configuration).



4.3.5 Language mode



4.3.6 Service mode



All previous settings are reinitialized when service mode is exited using the top up key .

**The error system**

The error system is divided into an error pending list and a status log list. Time is gained as days, minutes and hours since the error has occurred. The first 9 standing errors are stored in error pending. When an error is removed it is removed from error pending. The latest 9 errors are stored in the status log. When an error is removed it is still kept in status log. Errors in status log is stored for 180 days.

Error pending and status log are accessible when enabled in the operator menu.

5. Service


Often problems with unstable/wrong measurements occur due to insufficient/wrong earthing or potential equalization. Please check this connection. If OK, the SITRANS F M MAGFLO® transmitter can be checked as described under 9.1 and sensor under 9.3 in the handbook.

5.1 Transmitter check list

When checking SITRANS F M MAGFLO® installations for malfunction the easiest method to check the transmitter is to replace it with another MAG 5000/6000 transmitter with a similar power supply.

A replacement can easily be done as all settings are stored in and downloaded from the SENSORPROM® unit - no extra settings need to be made.

If no spare transmitter is available - then check transmitter according to check table.



## 5.2 Trouble shooting MAG transmitter

Symptom	Output signals	Error code	Cause	Remedy
<b>Empty display</b>	Minimum		1. No power supply	Power supply Check MAG 5000/6000 for bended pins on the connector
			2. MAG 5000/6000 defective	Replace MAG 5000/6000
<b>No flow signal</b>	Minimum		1. Current output disabled	Turn on current output
			2. Digital output disabled	Turn on digital output
			3. Reverse flow direction	Change direction
	Undefined	F70	Incorrect or no coil current	Check cables/connections
		W31	Measuring pipe empty	Ensure that the measuring pipe is full
		F60	Internal error	Replace MAG 5000/6000
<b>Indicates flow with no flow in pipe</b>	Undefined		Measuring pipe empty	Select empty pipe cut-off
			Empty pipe cut-off is OFF	Ensure that the measuring pipe is full
<b>Unstable flow signal</b>	Unstable		Electrode connection missing/ electrode cable is insufficiently screened	Ensure that electrode cable is connected and sufficiently screened
			1. Pulsating flow	Increase time constant
			2. Conductivity of medium too low	Use special electrode cable
			3. Electrical noise potential between medium and sensor	Ensure sufficient potential equalization
			4. Air bubbles in medium	Ensure medium does not contain air bubbles
<b>Measuring error</b>	Undefined		5. High concentration of particles or fibres	Increase time constant
			Incorrect installation	Check installation
			P40 No SENSORPROM® unit	Install SENSORPROM® unit
			P44 CT SENSORPROM® unit	Replace SENSORPROM® unit or reset SENSORPROM® unit with MAG CT transmitter
			F61 Deficient SENSORPROM® unit	Replace SENSORPROM® unit
			F62 Wrong type of SENSORPROM® unit	Replace SENSORPROM® unit
	Maximum	F63 Deficient SENSORPROM® unit	Replace SENSORPROM® unit	
		F71 Loss of internal data	Replace MAG 5000/6000	
<b>Measuring approx. 50%</b>			Flow exceeds 100% of $Q_{max}$ .	Check $Q_{max}$ . (Basic Settings)
			W21 Pulse overflow	Change volume/pulse Change pulse width
<b>Loss of totalizer data</b>	OK	W20	Missing one electrode connection	Check cables
			Initializing error	Reset totalizer manually
<b>##### Signs in display</b>	OK		Totalizer roll over	Reset totalizer or increase totalizer unit

We have checked the contents of this manual for agreement with the hardware and software described. Since deviations cannot be precluded entirely, we cannot guarantee full agreement. However, the data in this manual are reviewed regularly and any necessary corrections included in subsequent editions. Suggestions for improvement are always welcomed.

Technical data subject to change without prior notice.

The reproduction, transmission or use of this document or its contents is not permitted without express written authority. Offenders will be liable for damages. All rights, including rights created by patent grant or registration of a utility model or design, are reserved.

Copyright © Siemens AG 05.2006 All Rights Reserved